


INSTALLATION INSTRUCTIONS

Multi-Piece Shower with a Side Discharge Drain with solid core, reinforced bottom



1145

This packet includes installation instructions for the Bestbath® products shown below.
(These instructions also available at www.bestbath.com)



INITIAL SETUP

Pre-Installation Prep	2
Preparing the Shower Pocket (For Multi-Piece Units) ...	2

PAN INSTALLATION

Installing A Shower Pan With A Side Discharge Drain	3
---	---

WALL INSTALLATION

Installing Shower Walls	4-6
-------------------------------	-----

**Before you begin installation,
please carefully read all instructions
regarding the proper installation of
your shower unit.**

Initial Setup

PRE-INSTALLATION PREP

1 CHECK PARTS INVENTORY

If any parts are damaged, immediately file a claim with the carrier. Minor damage (scuffs and scrapes) can be touched up later.

FOR SHOWER BASE ONLY

- Pan
- Screw-in Drain Screen

FOR MULTI-PIECE UNITS

- Side Walls
- Back Wall (1 or 2 pieces, depending on model)
- Joint Sealant
- Construction Adhesive (Depending on model)
- Suction Cups (Depending on model)
- *Optional:* Flange trim kit for walls

2 GATHER SUPPLIES

FOR SHOWER BASE ONLY

- Drywall Screws (1½")

FOR MULTI-PIECE UNITS

- Drywall Screws (1½")
- Shim Wedges
- Four pieces 2x4 lumber, 8 ft. long (For walls; see Step 2 at right)

Please read all instructions provided in this guide prior to installation.

PREPARING SHOWER POCKET (FOR MULTI-PIECE ONLY)



- 1 Mark and cut out drywall to fit back and side walls of shower. Remove drywall 1" beyond side wall and top nailing flanges. (Figures 1 and 2)

Figure 1




Figure 2

- 2 Install studs to provide support for flange and drywall attachment. (Figure 3)




Figure 3

- 3 Rough in plumbing valve and drain per manufacturer's specifications.

Pan Installation

INSTALLING A SHOWER PAN WITH A SIDE DISCHARGE DRAIN

! **CAUTION: IF NOT INSTALLED PROPERLY, THE SHOWER PAN MAY NOT PERFORM AS DESIGNED AND WILL NOT BE COVERED BY THE WARRANTY.**

- 1 Check shower pocket area level and for correct dimensions. Make sure framing does not interfere with the unit's drain pipe coupler.




Figure 4

- 2 **DRY-FIT THE PAN:** Set the pan in the pocket. You **MUST** use a level to ensure pan is level. Shim if necessary.




Figure 5




Figure 5 Top View

- 3 Remove unit from the framing pocket. Have a plumber prepare the drain pipe to interface with the drain pipe coupler.
- 4 Sweep the floor and remove all debris from pocket area, then position pan in pocket.

- 5 Make sure the unit drains properly by pouring water on the shower floor, or by verifying that there is a slope towards the drain with a level. If in doubt, remove the unit from the pocket and review the previous steps.





Figure 6

- 6 Predrill the nailing flanges to avoid cracking the gel coat and screw flanges to framing.
- 7 Screw the drain screen into the unit.

(continued on page 4)


Shower Wall Installation

INSTALLING SHOWER WALLS



- 1** To ensure proper installation, walls must be plumb. Use a long level to check studs and add shims at top or bottom, if needed, to achieve plumb.


Shim if needed



- 2** Place lower back wall panel. Shim if needed to ensure plumb.

Secure panel with a single screw in center stud.

- 3** Place upper panel and hold it in place with one screw near the center. **Do not completely tighten screw.** Add shims to keep wall straight if needed.




- 4** Drill plumbing holes in side wall panel; then proceed to side wall installation. (Step 5A or 5B on page 5)

INSTALLING SHOWER WALLS (CONTINUED)

If your walls have SnapJoint hardware as shown in 5A, proceed with steps A1 and A2 below.


5A SnapJoint Walls



A1 Installing valve wall:


If parts of the shower valve and/or pipe nipple stick out:

- (1) Completely insert side wall at an angle to clear plumbing;
- (2) Rotate the wall into place;
- (3) Push wall until front is flush with pan.



A2 Installing non-valve wall:


Rest side wall on pan ledge, then push it into the wall channel until front is flush with pan.



If your walls have SpringClip hardware as shown in 5B, proceed with steps B1 through B3 below.


5B SpringClip Walls

- B1** Unless you are doing a dry fit first, apply a generous dollop of construction adhesive (included) between the flange and the back of each SpringClip as shown. After applying the adhesive, proceed directly to step B2.




B2 Installing valve wall:

- (1) Holding side wall angled inward, insert it at the lowest SpringClip first.
- (2) Pivot the wall up to engage the remaining clips.




- (3) Keep side wall completely inserted but still angled to clear the shower valve and/or pipe nipple.
- (4) Rotate wall over plumbing. Push wall in until front is flush with pan.




B3 Installing non-valve wall:

Holding side wall angled inward, insert it at the lowest SpringClip first, then rotate wall in to insert it at the higher clips. Push wall in until front is flush with pan.



INSTALLING SHOWER WALLS *(CONTINUED)*

- 6** With walls firmly pushed down and front edge of side wall aligned with front edge of pan, screw through side wall flanges into framing every 12" on center.



- 7** **For SnapJoint Walls ONLY:** With a suction cup on lower back wall panel, pull it firmly forward until back and side walls are pulled together. You will hear a series of clicks as the panel locking clip engages. Repeat with upper panel.

- 8** Screw top flange of back wall to studs.

- 9** Apply silicone caulk in all joints **except weep holes**, which are located near the front on the seam between the pan and side wall.